

Measure the top of the recess to the floor to ensure the right specifications are applied to your order.

If work tops are in the way just measure the height of the recess and then add on the height of the worktop to the floor.

